



Zakres fal	Pozycje przelacznika	
	P <sub>1</sub>	P <sub>2</sub>
I 16,5-51,5m	— 1'-2', 7'-8'	1'-2', 6'-7'-8' 9-10
II 187-572 "	6-12 1'-3'	1'-3', 7'-8' 9-10
III 1000-2600 "	— 1'-4'	1'-4' 9-10
Adapter	— 1'-5'	1'-5' 10-11

Poz. przelacznika P <sub>3</sub> (barwa dzwieku)	
	3'-4' —
	3'-5', 10'-11' 2-12
	3'-6' 2-12
	3'-7', 1'-10' 2-12

Schemat ideowy odb. TESLA 606A